

---

## REMOVAL AND INSTALLATION

### Convertible Top Assembly — Bows

#### Removal and Installation

1. Remove the convertible top headliner. For additional information, refer to Convertible Top Headliner in this section.
  2. Remove the screws and the appropriate convertible top frame bow(s).
  3. **NOTE:** Manually operate the convertible top frame before installing the headliner, to be sure the frame operates smoothly, without binding. To install, reverse the removal procedure.
-