


REMOVAL AND INSTALLATION

Fuel Lines and Fuel Filter — Exploded View



Item	Part Number	Description
1	—	Fuel tube bundle shield pushpin (part of 9E313)
2	W704652	Fuel tube bundle shield retaining bolt (2 required)
3	W520101	Fuel tube bundle clip retaining nut (2 required)

(Continued)

Item	Part Number	Description
4	9E313	Fuel tube bundle shield
5	W712583	Fuel tube bundle bracket retaining bolt
6	—	Fuel tube bundle bracket (part of 9J279)
7	9J279	Front fuel supply tube

(Continued)

REMOVAL AND INSTALLATION (Continued)

Item	Part Number	Description
8	—	Fuel tube bundle double pushpin retainer clip (part of 9J279)
9	—	Front fuel supply tube-to fuel filter quick connect coupling (part of 9J279)
10	9155B	Fuel filter
11	—	Rear fuel supply tube-to-fuel filter quick connect coupling (part of 9J279)

(Continued)

Item	Part Number	Description
12	—	Fuel tube bundle pushpin retainer clip (2 required)
13	9J279	Rear fuel supply tube
14	—	Rear fuel supply tube-to-fuel pump (FP) quick connect coupling (part of 9J279)

1. For additional information, refer to the procedures in this section.