

FUSES & CIRCUIT BREAKERS

Fig. 6: Battery Junction Box Legend
 Courtesy of FORD MOTOR CO.
 2003 Ford Mustang GT

Fuse	Amps	Circuits protected
F1.1	30 c.b.	Constant Control Relay Module (CCRM) – 3.8L
	50	Constant Control Relay Module (CCRM) – 4.6L
F1.2	30	Main light switch (11654), Multifunction switch
F1.3	40	Starter relay (11450), Ignition switch (11572)
F1.4	40	Ignition switch (11572)
F1.5	40	Ignition switch (11572)
F1.6	40	F2.1, F2.7, F2.9, F2.13, F2.15, F2.19, F2.21, F2.25, F2.27, F2.31, F2.33, F2.39
F1.7	–	not used
F1.8	50	ABS control module (2C219)
F1.9	20	Power point (19N236)
F1.10	30	Main light switch (11654)
F1.11	30	Rear window defrost relay
F1.12	40	Generic Electronic Module (GEM) (14B205)
F1.13	30	Subwoofer amplifier, luggage compartment right inboard, Subwoofer amplifier, luggage compartment right outboard
F1.14	20	Constant Control Relay Module (CCRM)
F1.15	30	Subwoofer amplifier, luggage compartment left outboard, Subwoofer amplifier, luggage compartment left inboard
F1.16	20	Horn relay
F1.17	20	ABS control module (2C219)
F1.18	30	Seat adjust switch, driver side front (14A701)
F1.19	10	Charge air cooler pump relay – Cobra
F1.20	20	Generator
F1.21	–	not used
F1.22	–	not used
F1.23	–	not used
F1.24	20	Constant Control Relay Module (CCRM)
F1.25	–	not used
F1.26	30	Constant Control Relay Module (CCRM)
F1.27	20	Daytime Running Lamps (DRL) module, Fog lamp relay
F1.28	30 c.b.	Convertible top raise relay, Convertible top lower relay

G00321574